## Measuring kits for N-operations

The revised DIN 14555-12 and the German fire brigades regulation FwDV 500 stipulate the necessary special equipment for relief forces possibly completed by additional instruments acc. to different hazard potentials and responsibilities.



For these requirements GRAETZ offers the following measuring kits:

## Measuring kit GW-G acc. to DIN 14555-12

1 pc. Transport case

6 pcs. ED150

6 pcs. film badges (without film)

1 pc. X5C plus

1 pc. GammaTest F (or version C)

1 pc. CoMo-170 F (or version ZS)

### Please note:

\* To be complemented with the Telescope Probe DE and the X5C *plus* in a separate aluminium transport case.

One kit GW-G in each vehicle.

# Measuring kit following the measuring concept NRW

1 pc. Transport case

4 pcs. ED150

4 pcs. film badges (without film)


1 pc. X5C plus

1 pc. CoMo-170 F (or version ZS)

#### Please note:


To be complemented with the Telescope Probe DE and the X5C plus, the gamma warning lamp GWL10m and the dose rate alarm unit GammaTest (version C or F). Three kits in each mobile command and

measuring truck.





Dose rate meter **X5C** *plus* for the measurement of  $\gamma$ - and X-rays.





Contaminaton monitor CoMo-170 F for a simultaneous and select ve  $\alpha$ -,  $\beta/\gamma$ -measurement. Detector surface 170 cm<sup>2</sup>.







04/2015

Subject to technical changes